

	COMPACT GRAND				COMPACT UPRIGHT						LOW-PROFILE CONSOLE														PORTABLE						
	CGP220	MPG200	MPG100	KAG100	CUP2A	CUP2	CUP1	CUP320	CUP310	CUP120	CUP110	M3W	MP20	MP120	MP15	MP10	KA150	KA130	M130	M110	M100	M230	M210	MPS20	MPS10	KA110	KA90	KP110	KP100		
Keyboard*	FW, W	FW, GH	FW, GH	FW	FW, GH	FW, GH	FW, GH	FW, GH	FW, GH	FW	FW	FW, GH	FW, GH	FW, GH	FW	FW	FW	FW	FW	FW	FW	FW, GH	FW, GH	FW, GH	FW	FW	FW	FW	FW	FW	
Wood Keys	Y	N	N	N	Y	Y	N	Y	N	N	N	Y	N	Y	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	
Triple-Sensor	N	N	Y	N	N	N	N	Y	Y	N	N	N	N	Y	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	
Escapement	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	
Sensitivity Levels	10	10	3	3 + 1 Fixed	10	10	3	10	10	10	10	10	10	10	10	10	6	6	0	7	0	10	4	10	10	4	4	3	3		
Display	10 char LCD	16 char LCD	Multi-function LCD	2x16 LCD	Scrolling LED	Scrolling LED	n/a	128 x 64 LCD	128 x 64 LCD	Scrolling LED	Scrolling LED	Scrolling LED	Scrolling LED	5X7 Dot Matrix	16 char LCD	Scrolling LED	7-segment 3-digit LED	7-segment 3-digit LED	n/a	7-segment 2-digit LED	n/a	5X7 Dot Matrix	7-segment 3-digit LED	Scrolling LED	Scrolling LED	Multi-functional LCD	7-segment 3-digit LED	Multi-functional LCD	Multi-functional LCD		
Polyphony	128	64	128	64	128	64	256	128	128	128	128	64	64	256	64	64	68	32	81	88	81	128	128	64	64	128	128	128	128		
Factory Programs	128	200	500	200	88	88	1	88	88	88	88	200	200	128	128	88	128	16	20	88	20	30	20	200	88	583	20	653	633		
Factory Setups	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	64	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
Piano Samples**	German 9' Grand	Triple Strike	Triple Strike	German 9' Grand	German 9' Grand	Triple Strike	German 9' Grand	German 9' Grand	German 9' Grand	German 9' Grand	German 9' Grand	Triple Strike	Triple Strike	German 9' Grand	Triple Strike	Triple Strike	Stereo PCM	Stereo PCM	Stereo PCM	Stereo PCM	Stereo PCM	Stereo PCM	Stereo PCM	Triple Strike	Triple Strike	Stereo PCM	Stereo PCM	Triple Strike	Triple Strike		
String Resonance	N	N	N	N	N	N	N	Y	Y	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	
Half-Damper	N	N	Y	N	N	N	Y	Y	Y	N	N	N	N	Y	N	N	N	Y	N	N	N	N	N	N	N	N	N	N	N	N	
Splits / Layers	Y	Y	Y	Y	N	Y	N	Y	Y	N	N	Y	Y	Y	Y	Y	Y	Y	N	Y	N	Y	Y	Y	Y	Y	Y	Y	Y	Y	
Dual Mode	N	N	Y	Y	Y	N	N	Y	Y	Y	Y	N	N	Y	N	N	Y	Y	N	Y	N	Y	Y	N	N	N	N	N	N	N	
Transpose	Y	Y	Y	Y	Y	Y	N	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	N	Y	N	Y	Y	Y	Y	Y	Y	Y	Y	Y	
Tune	Y	Y	Y	Y	Y	Y	N	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	N	Y	N	Y	Y	Y	Y	Y	Y	Y	Y	Y	
Effects	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	
Auto-Accompaniment	N	N	Y	Y	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	
Rhythms/Styles	100	100	200	100	0	78	N	69	69	78	0	100	100	Y	60	78	26	0	N	28	0	30	12	100	78	230	50	240	220		
Metronome	Y	Y	Y	Y	Y	Y	N	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	N	Y	N	Y	Y	Y	Y	Y	Y	Y	Y	Y	
Recorder	2 track 20 song	2 track 20 song	6 Track 10 song	2 track 1 song	1 track 1 song	1 track 9 song	None	1 track 10 song	1 track 10 song	1 track 1 song	1 track 1 song	2 track 20 song	2 track 1 song	1 track 4 song	2 track 9 song	2 track 1 song	5 song	None	1 track 1 song	None	1 track 1 song	1 track 1 song	2 track 20 song	1 track 9 song	6 track 5 song	1 track 5 song	6 track 10 song	1 track 10 song	1 track 10 song		
General MIDI	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	
Demo Songs	51	51	5	71	51	51	50	51	51	51	51	51	51	50	50	51	1	50	50	50	50	50	50	51	51	5	2	8	8		
Educational Features	N	N	N	Y	N	N	N	N	N	N	N	N	N	Y	N	N	Y	N	N	Y	N	N	Y	N	N	N	N	N	N	N	
Sound System	200-watt 4-spkr	200-watt 4-spkr	40W+20W 4-spkr	20W+15W 4-spkr	150-watt 3-way 6-spkr	140-watt 4-spkr	100-watt 4-spkr	25-watt 4-spkr	25-watt 4-spkr	45-watt 4-spkr	45-watt 4-spkr	50-watt 4-spkr	50-watt 4-spkr	50-watt 4-spkr	30-watt 2-way 4-spkr	30-watt 2-way 4-spkr	40-watt 2-spkr	30-watt 2-spkr	40-watt 2-spkr	15-watt 2-spkr	30-watt 2-spkr	20-watt 2-spkr	30-watt 2-spkr	30-watt 4-spkr	30-watt 2-spkr	80-watt 4-spkr	60-watt 4-spkr	10-watt 2-spkr	3-watt 2-spkr		
Audio Outs	Stereo RCA	Stereo RCA	Stereo 1/4"	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo 1/4"	Stereo 1/4"	Stereo 1/4"	Stereo 1/4"	Stereo 1/4"	Stereo 1/4"
Audio Ins	Stereo RCA	Stereo RCA	Stereo 1/4"	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo RCA	Stereo 1/4"	Stereo 1/4"	Stereo 1/4"	Stereo 1/4"	
1/8" MP3 In	N	N	N	N	N	N	Y	Y	N	N	Y	N	N	Y	N	N	Y	N	N	N	N	Y	Y	N	N	N	N	N	N	N	
Mic In	N	N	N	N	N	N	Y	N	N	N	N	N	Y	N	N	Y	N	Y	Y	N	Y	N	N	N	N	N	N	N	Y	Y	
Headphone	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	2	1	1	
MIDI I/O	In Out Thru	In Out Thru	In Out	- Out	In Out Thru	In Out	via USB	In Out	In Out	In Out	In Out	In Out	In Out	via USB	In Out	In Out	via USB	via USB	via USB	via USB	via USB	via USB	In Out	In Out	In Out	via USB	In Out	In Out	via USB	via USB	
USB-MIDI	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	
USB-Audio	N	N	N	Y	N	N	Y	N	N	N	N	N	Y	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	
Bluetooth	N	N	N	Y	N	N	Y	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	
Switch Pedals	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	Sustain Sostenuto Soft	
Expression Pedal input	Y	Y	N	N	Y	Y	N	Y	Y	Y	Y	N	Y	N	N	N	N	N	N	N	N	N	N	Y	N	N	N	N	N	N	
Finishes***	EP	EP	EP	EP	EP, IP	EP	EP, IP	SR, WH	SR, WH	EP, SR	EP, SR	SR, WH	EP, SR	SG, PR	SR	EP, SR	SR, W	SR, WH	SR	SR, WH, MH	SR, WH	SR, WH	SR, WH	SR, WH	SR, WH	SR, WH	SR, WH	SR, WH	SR, WH	SR, WH	
Bench	Included	Included	Included	Included	Included	Included	Included	Included	Included	Included	Included	Included	Included	Included	Included	Included	Included	Included	n/a	Included	Optional	Included	Included	Included	Included	Optional	Optional	n/a	n/a	Optional	Optional
Music Stand	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Built-in	Optional	Optional	Included	Included	Included	Included
Power	Internal	Internal	Internal	Internal	Internal	Internal	External	External	External	External	External	External	External	External	External	External	External	External	External	External	External	External	External	External	External	External	External	External	External	External	External

\* Keyboard Mechanisms: FW = fully-weighted hammer-action / GH = graded-hammer  
\*\* The German 9' Grand features the same samples as used in the Artis® pro stage piano.  
\*\*\* Finishes: SR= Simulated Rosewood; EP = Ebony Polish; IP = Ivory Polish; MBP = Matte Black Plastic; MH = Mahogany; PR = Princess Rose; SG = Snow Grained; WH = White; WO = White/Orange.